

easicook.co.uk

Spare Parts Manual


**Leading UK Distributors
of Catering Equipment Since 1977**

Sales - Repairs - Spares

Tel: 029 20747567

Fax: 029 20214100

Email: info@easicook.co.uk



Model	Explode	Code	Description	Stocked Line	Special Order	Not Available
T318	1	AA100	Lower Panel	-	-	x
T318	2	AA101	Upper Panel	-	-	x
T318	3	AA102	Show Lamp Board	✓	-	-
T318	4	AA226	On/Off Switch	✓	-	-
T318	5	AA104	Upper Edge Panel	-	-	x
T318	6	AA105	Top Board	-	-	x
T318	7	AA106	Door	✓	-	-
T318	8	AA107	Ice Scoop	✓	-	-
T318	9	AA109	Left Side Panel	-	-	x
T318	10	AA191	Shelf of Ice-flipping	✓	-	-
T318	11	AA111	Cabinet Liner	-	-	x
T318	12	AA112	Water Box	✓	-	-
T318	13	AA113	Shelf of Water Box	✓	-	-
T318	14	AA114	Evaporator Fixer	✓	-	-
T318	15	AA124	Screw of Quit Stopping	✓	-	-
T318	16	AA257	Butterfly Shape Washer	✓	-	-
T318	17	AA117	Washer	✓	-	-
T318	18	AA118	Positional Switch	✓	-	-
T318	19	AA119	Motor Connecting Axis	✓	-	-
T318	20	AA128	Backstop	✓	-	-
T318	21	AA120	Turning Motor Fixer	✓	-	-
T318	22	AA195	Motor pin	✓	-	-
T318	23	AA122	Eccentricity Wheel	✓	-	-
T318	24	AA123	Motor Rotational Axis	✓	-	-
T318	25	AA115	Stopping Nut for Motor Connecting Axis	✓	-	-
T318	26	AA125	Tray Motor	✓	-	-
T318	27	AA126	Connecting Rod	✓	-	-
T318	28	AA128	Backstop	✓	-	-
T318	29	AA127	Water Box Axis Pin	✓	-	-
T318	30	AA129	Water-level Sensor	✓	-	-
T318	31	AA130	Axletree Bearing	✓	-	-
T318	32	AA131	Axletree Locking Collar	✓	-	-
T318	33	AA196	Paddle Rod Cover II	✓	-	-
T318	34	AA133	Spring	✓	-	-
T318	35	AA134	Paddle Rod Cover I	✓	-	-
T318	36	AA198	Paddle Agitator	✓	-	-
T318	37	AA136	Paddle Rod	✓	-	-
T318	38	AA252	Alnico Magnet	✓	-	-
T318	39	AA138	Alnico Magnet Cover	✓	-	-
T318	40	AA139	Paddle Motor Fixer	✓	-	-
T318	41	AA140	Nylon Joint Axis	✓	-	-
T318	42	AA141	Paddle Motor	✓	-	-
T318	43	AA142	Back Panel	-	-	x
T318	44	AA143	Elbow of Affusion	-	12 weeks	-
T318	45	AA144	Upper Shelf	-	-	x
T318	46	AA145	Evaporator	✓	-	-
T318	47	AA147	Diffused Device	-	12 weeks	-
T318	48	AA149	Supply Water Pipe	✓	-	-
T318	49	AA148	Suction Pipe I	✓	-	-
T318	49	AA146	Suction Pipe II	✓	-	-
T318	50	AA164	Magnet Valve	✓	-	-
T318	51	AA150	Drainage Connector	✓	-	-
T318	52	AA151	Sealing Gasket	✓	-	-
T318	53	AA152	Elbow of Drainage	✓	-	-
T318	54	AA154	Water Inlet Tube	✓	-	-
T318	55	AA171	Fan	✓	-	-
T318	56	AA165	Filter Fixer	✓	-	-
T318	57	AA166	Filter	✓	-	-
T318	58	AA168	Condenser	✓	-	-
T318	59	AA167	Compressor	✓	-	-
T318	60	AA162	Steel	-	-	x
T318	61	AA155	Power Supply Plug	-	-	x
T318	62	AA156	Water Inlet Tube White Sealing Washer	✓	-	-
T318	63	AA212	Valve of Water Inlet Tube	✓	-	-
T318	64	AA158	Drainage Pipe	✓	-	-
T318	65	AA159	Water Valve Fixer	✓	-	-
T318	66	AA160	Y-Pipe for Water Discharge	✓	-	-
T318	67	AA161	Ice Water Discharge Tube	✓	-	-
T318	68	AA161	Ice Water Discharged Tube	✓	-	-
T318	69	AA169	Compressor Fixing Board	-	-	x
T318	70	AA170	Adjustable Feet	✓	-	-
T318	71	AA172	Grill	✓	-	-
T318	72	AA173	Right Side Panel	-	-	x
T318	73	AA174	Wiring Box	✓	-	-
T318	74	AA175	Ice-level Sensor	✓	-	-
T318	75	AA176	Ice-lever Sensor Fixer	✓	-	-
T318	76	AA178	Wire Fixer	✓	-	-
T318	77	AA233	Control Board Box & Cover	✓	-	-
T318	78	AB851	Main Control Board R134a	✓	-	-
T318	78	AA181	Main Control Board R600	✓	-	-
T318	79	AA182	Hall Device	✓	-	-
T318	80	AA183	Hall Device Fixer	✓	-	-
T318	n/a	AA153	Pressure Control Valve	✓	-	-
T318	n/a	AA177	PVC Tube	-	-	x