

easicook.co.uk

Spare Parts Manual

Leading UK Distributors
of Catering Equipment Since 1977

Sales - Repairs - Spares


Tel: 029 20747567

Fax: 029 20214100

Email: info@easicook.co.uk



SERIES S 35 - 40 - 50



DRAWING	DESCRIPTION	S35	S40	S50
1/A	COMPLETE CABINET	60000	70000	80000
1/C	TOP LID/SWITCH PANEL	60003	70003	80003
2	UNDER DOOR PANEL	60004	70004	80004
3/A	DOOR	60131	70131	80131
4/A	REAR PANEL	60006	70006	80006
5	RINSE TANK BOILER	60930	60930	80930
6/D	COMPLETE RIGHT HINGE	17910DX	17910DX	17910DX
6/S	COMPLETE LEFT HINGE	17910SX	17910SX	17910SX
20	WRAS TO SOLENOID CONNECT PIPE	30762	30762	30764
21	WATER INLET PIPE	30760	30760	30760
22/A	LOWER RINSING ARM PIPE	23020	23020	23020
22/B	UPPER RINSING ARM PIPE	30765	30765	30767
23/A	WASTE PIPE / GREY CONCERTINA	30770	30770	30770
23/B	DRAIN PUMP PIPE		23030	23030
24	UPPER WASH CONNECTION PIPE			30768
25	UPPER WASH Y CONNECTOR			16005
28	WASH MOTOR SUCTION INLET PIPE	23035	23035	23035
29	WASH MOTOR OUTLET CONNECTOR PIPE	23016	23016	23019
30/A	WASH PUMP	60650	60650	50650
30/B	WASH PUMP CAPACITOR	30645	30645	50645
32/B	RINSE AID DOSING PUMP	30683	30683	30683
32/D	DETERGENT DOSING PUMP	30673	30673	30673
32/TB	RINSE AID PUMP PERI TUBE	23063	23063	23063
32/TD	DETERGENT PUMP PERI TUBE	23062	23062	23062
32/E	DUAL RINSE/DETERGENT PUMP	60675	60675	60675
32/F	RINSE AID PUMP NON RETURN VALVE	30720	30720	30720
33	SOLENOID	30600	30600	30600
34/A	START CYCLE PUSH BUTTON	30422	30422	30422
34/B	DRAIN PUSH BUTTON			30424
34/C	POWER ON/OFF SWITCH	30424	30424	30423
37	RELAY CONTACTOR			30520
38	CYCLE TIMER 2 MINUTE	30450	30450	30450
39	PRESSURE SWITCH	30530	30530	30530
40	DRAIN PUMP	30660	30660	30660
41/A	VARIABLE THERMOSTAT WASH	30510	30510	30510
41/B	THERMOSTAT KNOB	30515	30515	30515
41/C	VARIABLE THERMOSTAT RINSE	30514	30514	30514
42	SAFETY THERMOSTAT	30517	30517	30517
44/B	1.5 KW WASH ELEMENT	60645	60645	60645
45	3KW RINSE ELEMENT	60640N	60640N	30640
46/A	GREEN PILOT LIGHT	30435	30435	30435
47	DOOR MICROSWITCH	30610	30610	30610
60/B	COMPLETE WASH AND RINSE ARM	30950P	30950P	80950P
60/S	LOWER WASH PIPE	30380	30380	50380
60/D	LOWER WASH PIPE	30370	30370	50370
61/S	LOWER RINSE PIPE	30400	30400	70390
61/D	LOWER RINSE PIPE	30390	30390	70400
62/S	UPPER RINSE PIPE	30400	30400	70390
62/D	UPPER RINSE PIPE	30390	30390	70400
65	UPPER WASHING INLET PIPE			23037
70/A	LOWER WASH/RINSE DISTRIBUTOR	20070A	20070A	20070B
71	WASHING GROUP O RING	18025	18025	18025
72/A	SPLASH GUARD	20135P	20135P	20135P

72/B	WASHING GROUP FIXING NUT	20017	20017	20017
73	WASHING GROUP SEAL	20016	20016	20016
74/A	TWO WAYS PARALLEL WASH BOSS	20015	20015	20015
74/B	UPPER RINSE BOSS	20020	20020	20020
75/A	WASH JET	20049	20049	20049
75/B	FIXED UPPER WASH JETS			20040
76	RINSE JET	17025	17025	17025
77/A	WASH RING OMEGA	20014	20014	20014
77/B	RINSE RING OMEGA	20013	20013	20013
78	M8 BRASS RETAINER	17180	17180	17180
79/A	UPPER RINSING TURRET	30981	30981	30981
79/B	O RING	18005	18005	18005
79/C	WATER 3/4 GASKET	19050	19050	19050
80	WASHING GROUP STAINLESS STEEL SHAFT	17045	17045	17045
82/A	COMPETE PUMP FILTER	15905	15905	15905
82/B	PUMP FILTER HAND WHEEL	120480	120480	120480
82/C	TANK FILTER			80010
82/D	TANK HEATING ELEMENT FILTER			80011
83	SOAP ELBOW	16920	16920	16920
85/A	SUCTION DRAIN ELBOW	20090	20090	20090
85/B	DRAIN ELBOW GASKET	19000	19000	19000
85/C	DRAIN ELBOW NUT	17060	17060	17060
86	FOOT	15135	15135	15135
87	CUTLERY HOLDER	30750	30750	30750
88	SAUCER HOLDER	30740	30740	30740
89/A	DISH BASKET			C00011
89/A	GLASS BASKET	C0001	C0001	C0005
90	ANTI POLLUTION DEVICE	30603	30603	30603
90	WRAS INLET VALVE	30606K	30606K	30606K
91	CABLE FASTNER	60590	60590	60590
92	COMPLETE AIR RETAINER	20100	20100	20100
93	DOOR TIE ROD BLOCKS	20150	20150	20150
94	HEATING ELEMENT CONNECTION COVER	20155	20155	20155
95	UPPER WASH CONNECTOR			17175
96	DRAIN PLUG	104321	104321	106321
96/A	WASH PIPE CAP	20050	20050	20050
96/B	O RING WASHING PIPE CAP	18000	18000	18000
96/C	RINSING PIPE CAP	20055	20055	20055
96/D	O'RING RINSING PIPE CAP	18010	18010	18010
99	COMPLETE DOOR CLOSING	20132	20132	20132