

easicook.co.uk

Spare Parts Manual

Leading UK Distributors
of Catering Equipment Since 1977

Sales - Repairs - Spares


Tel: 029 20747567

Fax: 029 20214100

Email: info@easicook.co.uk

[Click Here for Live Online Chat](#)

Spare parts suitable for:
ATA



A

Suitable for Ata



Wash and rinse systems

Page 3



Various and air traps

Page 6




Drain and filter systems

Page 7



Door and hood components

Page 8



Electrical components

Page 9



Dosing pumps

Page 13



Heating elements and boilers

Page 14



Pumps and components

Page 15

Wash and rinse systems




Item	Order	Description	Model	OEM
1	516144	wash jet holder	AL10, AL11, AL30, AL16	7114
2	516021	O-ring	AL30, AL31, AL35, AL36	7601
3	516107	wash jet	AL40, AL41 (to 30.3.94)	1002
4	516108	wash jet cap	AL45, AL46 (to 30.3.94)	1003
5	516051	wash end cap		7602
6	516121	wash end cap	AL50 (from 30.3.94)	4114
7	516167	O-ring		4643
8	516117	wash jet cap	AL50	4103
9	516116	wash spinner		4102
10	516020	wash jet (rotating arm)		7117
11	516021	O-ring		7601



Item	Order	Description	Model	OEM
1	516005	disc	AL03, AL05	7104
2	516148	wash arm spindle	AL03, AL05	7350
3	516003	disc (teflon)	AL03, AL05	7102
4	516002	bush	AL03, AL05	7101
5	516001	gasket	AL03, AL05	7138
6	516140	wash arm support	AL03, AL05	4375



Item	Order	Description	Model	OEM
1	516005	disc		7104
2	516004	wash arm shaft	AL20, AL21, AL25, AL25,	7103
3	516003	disc (teflon)	AL40, AL41,	7102
4	516002	bush	AL45, AL46	7101
5	516000	wash arm support/ lower		7100



Item	Order	Description	Model	OEM
1	516018	centering piece		7923
2	516013	pin		7912
3	516017	ball bearing	AL40, AL41,	7918
4	516014	groove nut	AL45, AL46	7911
5	516015	gasket		7933
6	516016	locking ring		7934
7	516019	wash arm support/ upper	AL40 to AL46	7914
8	516155	ring	AL40 to AL46	7417
9	516184	gasket	(from 1.3.00)	6810
10	516183	wash arm support/ upper		6804
10	516238	wash arm support/ upper		4759
11	516155	ring	AL54	7417



Item	Order	Description	Model	OEM
1	510176	rinse jet holder		7116
2	510177	O-ring	AL	4648
3	510187	rinse jet swirl	AF	1000
4	510186	rinse jet cap	AT	1001
5	516050	rinse arm end cap		4649



Item	Order	Description	Model	OEM
1	510175	rinse jet holder		7127
2	510177	O-ring	AL	4648
3	510174	rinse jet swirl	AF	7128
4	510173	rinse jet cap	AT	7129
5	516050	rinse arm end cap		4649

A
Suitable for Ata



Item	Order	Description	Model	OEM
1	516199	rinse jet, 15° inclination/ right		7356A
2	516200	rinse jet		7356B
3	516149	rinse jet, 15° inclination/ left	AL03, AL05	7356E 7356C
4	516021	O-ring		7601



Item	Order	Description	Model	OEM
1	516006	wash arm cross		7105
2	516043	rinse cross	AL60, AF78, AF88	4622
3	516160	wash arm cross	AL54	7429



Item	Order	Description	Model	OEM
1	516186	rinse jet holder		6830
2	510177	O-ring		4648
3	516187	rinse jet swirl (grey)	AL40 -AL46 1.3.00	6831
4	516205	rinse jet cap		6832
5	516201	wash jet		6829




Item	Order	Description	Model	OEM
1	516006	wash arm cross		7105
2	516043	rinse cross		4622
2	516022	O-ring		7130
3	516023	disc		7131
4	516024	cut ring		7132
5	516025	nut, 1/2"		7133
6	516026	O-ring		7134
7	516027	ring 3/4"		7135
8	516028	cut ring		7136
9	516029	nut, 3/4"		7137




Item	Order	Description	Model	OEM
1	516207	rinse arm/ right	AL20, AL21, AL40, AL41, AL45, AL46	7106
2	516208	rinse arm left	(to 30.3.94)	7107
3	516209	wash arm/ right		7108
4	516210	wash arm/ left		7109



Item	Order	Description	Model	OEM
1	516009	rinse arm/ right	AL20, AL21,	7902
2	516010	rinse arm/ left	AL25, AL26,	7903
3	516007	wash arm/ right	AL40, AL41, AL45, AL46,	7904
4	516008	wash arm/ left	(from 30.3.94)	7905



Item	Order	Description	Model	OEM
1	516150	rinse arm/ right	AL03, AL05	7368
2	516151	rinse arm/ left		7369
3	516152	wash arm/ right		7370
4	516239	wash arm/ left		7352




Item	Order	Description	Model	OEM
1	516158	rinse arm/ right	AL54	7420
2	516159	rinse arm/ left	AL54	7421
3	516156	wash arm/ right	AL54	7418
4	516157	wash arm/ left	AL54	7419



Item	Order	Description	Model	OEM
1	516039	rinse arm/ right	AL60, AF78, AF88, AT95, AT96, AT105, AT106	4627
2	516040	rinse arm/ left		4628
3	516211	wash arm	AL60 (to 30.3.94), AF78, AF88 (to 30.3.94), AT95 (to 30.3.94), AT105 (to 30.3.94), AL (from 30.3.94), AF78, AF88 (from 30.3.94), AT95, AT105 (1.5.94), AT110, AT112, AT114, AT116	4602
4	516191	wash arm		9630



Item	Order	Description	Model	OEM
1	516129	bush		4334
2	516139	spindle	AL55,	4374
3	516133	ring	AF61 to AF88	4364
4	516164	reducer	(from 1.10.98)	4446
5	516130	column		4341
6	516132	column	AF61 to AF88	4362
7	516141	gasket	AF61 to AF88,	4391
8	516137	wash arm support/ lower	(since 1.10.98), AL55	4369



Item	Order	Description	Model	OEM
1	516153	rinse arm	AL03, AL05	7381
2	516171	rinse arm	AL55, AF61,	4752
3	516134	wash arm	AF78, AF88 (from 1.10.98)	4365
4	516049	rinse arm	AT95, AT105 (from 1.5.94), AT110, AT112, AT114, AT116	9714



Item	Order	Description	Model	OEM
1	516129	bush		4334
2	516138	spindle	AL55,	4373
3	516133	ring	AF61 to AF88	4364
4	516001	gasket	(from 1.10.98)	7138
5	516172	wash arm support/ upper		4756



Item	Order	Description	Model	OEM
1	516005	disc		7104
2	516004	wash arm spindle		7103
3	516003	disc (teflon)		7102
4	516002	bush	AL40 to AL46	7101
5	516155	gasket	(from 1.3.00), AL54	7417
6	516212	extension		7416
7	516154	column		7415
8	516141	gasket		4391
9	516137	wash arm support/ lower		4369




Item	Order	Description	Model	OEM
1	516044	disc		4623
2	516042	O-ring		4615
3	516035	spindle	AL66, AF78, AF88, AT95, AT96, AT105, AT106	4621
4	516165	bush		4608
5	516037	gasket		4603
6	516166	groove nut		4637
7	516030	wash arm support/ lower		4620
-	n. l. a.	extension	AT95, AT96, AT105, AT106	4612
8	516031	gasket		4619

Suitable for Ata



Item	Order	Description	Model	OEM
1	516035	spindle	AL60, AF78,	4625
2	516037	gasket	AF88, AT95,	4603
3	516165	bush	AT96, AT105,	4608
4	516032	wash arm support/ upper	AT106	4624



Item	Order	Description	Model	OEM
1	516048	bush	AT95, AT105	9632
2	516047	spindle	(from 1.3.94),	9631
3	516046	reducer		9594
4	516045	wash arm support/ lower/ upper	AT110, AT116	9601



Item	Order	Description	Model	OEM
1	516235	conversion kit	AL10/15/16	A6862
2	516236		AL30/31	A6863
3	516237		AL35/36	A6864
4	516001	gasket		7138



Item	Order	Description	Model	OEM
1	516119	basket turn table compl.		4105
2	516122	holder	AL50, AF73, AF83	4115
3	516118	gasket		4104
4	516031	gasket		4619

Various



Item	Order	Description	Model	OEM
1	516101	back flow restrictor		1605, 1610




Item	Order	Description	Model	OEM
1	516083	T-fitting		1056
2	516082	T-fitting		7947
3	516103	cross		3001

Softeners



Item	Order	Description	Model	OEM
1	516086	softener		7211
2	530000	softener		7641
3	510929	salt container		7642

Air traps



Item	Order	Description	Model	OEM
1	516218	air trap	AL30 to AL46	7140
2	516219	air trap	AL50, AL60, AF73, AF88, AL03 to AL05,	4660
3	516077	air trap	AL10 to AL26, AL30 to AL46 (from 5.3.91), AL54, AL55	7690
4	516169	air trap	AL50, AL60 (from 5.3.91), AF73, AF88 (from 5.3.91)	4690


Drain and filter systems



Item	Order	Description	Model	OEM
1	510436	drain plug	AL10 to AL46	7150
2	516204	drain elbow	AL10 to AL46	7151
3	516068	gasket 1"	AL10 to AL46	7152
4	516069	nut	AL10 to AL46	7153
5	516146	gasket	AL10 to AL46	7201
6	516070	drain elbow 1"	AL10 to AL46	7154




Item	Order	Description	Model	OEM
1	516084	drain plug	AL03, AL0F	1107
2	516109	drain seating	AL03, AL0F	1071
3	516042	gasket	AL03, AL0F	4615
4	516110	elbow	AL03, AL0F	1072




Item	Order	Description	Model	OEM
1	516079	filter	AL10 to AL46	1029
2	516161	filter	AL03, AL05	7855
3	516120	filter	AL50, AL60, AF73 to AF88, AT95, AT96	4112
4	560147	lock screw		1013



Item	Order	Description	Model	OEM
1	516173	filter	AL54, AL55	4844
2	516128	locking nut		4333
3	516185	filter	AL10, AL40 to AL46 (from 1.3.00)	6820
4	516215	filter	AF61 to AF78 (1.10.98)	4750



Item	Order	Description	Model	OEM
1	516131	filter	AF61 to AF78	4352
2	516216	filter	AF88 (from 1.10.98)	4758
3	516195	filter	AF88 (from 1.3.00), AT95, AT105, AT110, AT112, AT114, AT116	9722
3	516217	filter	AF88 (from 1.10.98)	9718



Item	Order	Description	Model	OEM
1	516196	filter	AT95 to AT116 (from 1.10.98)	9723
2	516197	filter		9724



Item	Order	Description	Model	OEM
1	510766	drain plug	AL50, AL60, AF73, AF78	4121
2	516106	drain plug	AF61 to AF98 (from 1.10.98)	9629
3	516124	drain plug	AL54, AL55	4134
4	510767	drain plug	AF83, AF88, AT95, AT96, AT105, AT106	5121
5	516066	drain plug	AT95, AT105 (from 1.5.94) AT110, AT112, AT114, AT116	9625

A
Suitable for Ata



Item	Order	Description	Model	OEM
1	516071	drain seating	AL50, AL60, AL54,	4122
2	516123	gasket	AL55, AF73, AF78,	4123
3	516073	nut	AF83, AF88, AT95,	4124
4	516074	gasket	AT96, AT105, AT106,	4125
5	516076	elbow	AT110, AT112,	4126
6	516136	elbow	AT114, AT116	4126
7	516053	elbow	AF61 to AF78 (from 1.10.98)	4368
8	516053	hose connector	drain pump model	4640
8	516075	nut		4127

Hoses



Item	Order	Description	Model	OEM
1	516054	inlet hose	AL10, AL11,	7630
2	516060	outlet hose	AL15, AL16	7631
3	516055	inlet hose	AL20, AL21, AL25, AL26, AL30, AL31,	7170
4	516061	outlet hose	AL35, AL36, AL40, AL41, AL45, AL46	7171



Item	Order	Description	Model	OEM
1	516188	inlet hose	AL30, AL31,	6809
2	516062	outlet hose	AL40, AL41, AL45, AL46 (from 1.10.98)	7943
3	516054	inlet hose	AL03, AL05	7630
4	516060	outlet hose		7631



Item	Order	Description	Model	OEM
1	516057	inlet hose		4638
2	516125	outlet hose	AL50, AL60, AF73, AF78	4137
3	516061	outlet hose	AF61, AF73, AF78, AL50, AL60 (from 30.3.94)	7171
4	516062	outlet hose	AL54, AL55	7943




Item	Order	Description	Model	OEM
1	516058	inlet hose	AF83, AF88	4639
2	516064	outlet hose	AF83, AF88	4647
3	516142	inlet hose	AF61, AF88 (from 10.98)	4393
4	516143	outlet hose	AF88 (from 10.98)	4398




Item	Order	Description	Model	OEM
1	516058	inlet hose	AT95, AT96,	4639
2	516057	outlet hose	AT105, AT106	4638
3	516059	inlet hose	AT95 to AT116 (from 1.5.94)	9706
4	516065	outlet hose		9651

Door components




Item	Order	Description	Model	OEM
1	516089	spring clamp	AL10 to AL46	7161
2	516145	spring	AL10 to AL46	7166
3	516090	spring		7162
4	516091	cotter pin		7167
5	516170	door catch	AL03, AL05	4713




Item	Order	Description	Model	OEM
1	516115	spring clamp	AL50, AL60	4086
2	516114	spring right	AL54, AL55	4082
3	516090	spring right	AF61, AF73, AF78, AF83	7162
4	516091	cotter pin	AF88	7167

Hood components



Item	Order	Description	Model	OEM
1	516176	hood strap		6086
2	516177	hood strap nut		6087
3	516178	hood strap pin		6088
4	516179	handle insert	AT95, AT96, AT105, AT106	6090
5	n. l. a.	strand	(to 1.5.94)	6620
6	516175	spring		6083
7	516180	tension adjustor		6091



Item	Order	Description	Model	OEM
1	516192	castor		9634
2	516228	shaft		9619
3	516198	circlip	AT (from 1.5.94)	52061
4	516194	cable		9713
5	516193	cable clamp		9643

Electrical components

Switches



Item	Order	Description	Model	OEM
1	110091	knob		4226
2	110741	surround		7913
3	110718	knob		6826



Item	Order	Description	Model	OEM
1	345025	main switch	AL10, AL15, AL20, AL25, AF73, AF78, AF83, AF88, AF73PS, AF78PS	7606 4202
2	345455	main switch	AL11, AL16, AL21, AL26, AL31, AL36, AL41, AL46, AL40PS, AL45PS	7951
3	345448	main switch	AL30, AL35, AL40, AL45 (-3.'00), AL40D, AL45D, AF61W, AF88	7950




Item	Order	Description	Model	OEM
1	345022	main switch	AF61, AF78, AF61D, AF61DPS, AF61PS	4277
2	345468	main switch	AF78D, AF78DPS, AF78PS	4276
3	345458	main switch	AF95, AF105, AF110	9804



Item	Order	Description	Model	OEM
1	345456	program switch	AL30, AL35, AL40, AL45 n(-2.'00), AL31, AL36, AL41, AL46	7952
2	345449	program switch	AL40, AL45 (from 3.'00), AL40PS, AL45PS	6827
3	345467	program switch	AF61PS, AF78, AF88, AF78PS, AF78D	4274




Item	Order	Description	Model	OEM
1	345451	program switch	AF73, AF78, AF73PS, AF78PS	4221
2	345469	program switch	AF78DPS	4275



Item	Order	Description	Model	OEM
1	345466	switch/ regeneration	AL40D, AL450, AF61D	4273
2	345453	switch/ drain pump	AL50PS, AL60PS	4235


Suitable for Ata



Item	Order	Description	Switch combination	OEM
1	345027	switch unit	AL30 to AL46, AL50, AL60	7205
2	345434	switch unit	AL31, AL35, AL41, AL46	7208



Item	Order	Description	Switch combinations	OEM
1	345463	switch unit	AL03, AL05, AL54, AL55	4716
2	345465	switch unit	AL05D, AL54D, AL55D	7373



Item	Order	Description	Switch combinations	OEM
1	345464	switch unit	AL05 (from 1.2.00)	7372
2	345452	push button	AF73, AF78, AF83, AF88, AT95, AT96, AT105, AR106	4232
3	345462	push button	AF61, AF73 to AF88 (from 1.3.00)	6954

Signal lamps



Item	Order	Description	Model	OEM
1	359008	lamp unit	AL03, AL05, AL30 to AL60	7206




Item	Order	Description	Model	OEM
1	359353	lamp (green)	AL10 to AL26,	4223
2	359355	lamp (blue)	AF73 to AF88,	4224
3	359352	lamp (clear)	AT95, AT96, AT105	7622
2	359356	lamp (red)	AF	4225




Item	Order	Description	Model	OEM
1	359130	signal element, 230V		7215
1	359351	signal element, 230V	only for greens ocket	7216
2	359350	signal element, 230V	only for blue socket	7224
3	359124	insert socket		7953

Micro switches




Item	Order	Description	Model	OEM
1	345032	micro switch	AL30 to AL46, AL50, AL60, AF73 to AF88, AT95 to AT106	4203
2	345460	micro switch	AL10 to AL20	7620
3	345459	micro switch	AL10 to AL26 (from 30.3.94)	7607



Item	Order	Description	Model	OEM
1	345116	magnetic switch		13105

Timers




Item	Order	Cycle time	Rinse time	Cams	Model	OEM
1	360032	150"	15	2		2512
2	360031	150"	20	3		1083




Item	Order	YZ1	YZ2	YZ3	Model	OEM
1	360090	120"			AL10, AL20, AL15, AL25, AL30, AL40, AL35, AL45, AL50, AL60, AF61	7203 7287
2	360140	120"			AL31, AL41, AL36, AL46	7223
3	360142	120"			AL03, AL05, AL54, AL55, AL40D, AL45D, AL40, AL45 (from 1.3.00)	4717



Item	Order	Description	Model	OEM
1	360138	regeneration	AL11, AL21, AL16, AL26, AF61D, AF78D	7643 7287
2	360091	regeneration	AL31, AL41, AL36, AL46	7213
3	360143	regeneration	AL03D, AL05D, AL40D, AL50D, AL54D, AL55D	4718



Item	Order	Description	Model	OEM
1	360137		AF73 to AF88	4240, 4254
2	360141		AT98 to AT106	6680




Item	Order	Description	Model	OEM
1	360139		AT95, AT105 (from 1.5.94)	9813
2	360144		AT95, AT105, AT110 (from 1.10.98)	9815
3	110092	knob		4228

Pressure switches




Item	Order	Switching range	Model	OEM
1	541140	55/30	AL10 to AL46, AL54, AL55	1004
2	541132	40/18	AL10 to AL16	6850
3	541141	75/35	AL03, AL05, AL50, AL60, AF73 to AF88, AT95 to AT106	4210
4	541142	123/75	AF61, AF78 to AF88 (from 1.10.98), AT95 to AT106 (from 1.5.94)	9830

Thermostats



Item	Order	Description	Model	OEM
1	390006	0 - 90 °C	AL10 to AL60, AF73 to AF88, AF61, AT95 to AT106	7280, 1080, 2080
2	390421	0 - 90 °C	AL03, AL05, AL10 to AL26, AL54, AL55, AL40 to AL46 (from 1.3.00)	7608
3	110092	knob		4228



Item	Order	Description	Model	OEM
1	390231	safety thermostat	AL03, AL05	7680
2	390420	safety thermostat		4280

Relays



Item	Order	Description	Model	OEM
1	380130	3 pole		1075
2	380350	relay		7711


A

Suitable for Ata



Item	Order	Description	OEM
1	380478	contactor, 24V, 2 NO + 2 NC	4241
2	380212	contactor, 230V, 3 NO + 1 NC	4204
3	380213	contactor, 230V, 3 NO + 1 NC	9800

Various



Item	Order	Description	Model	OEM
1	550411	connector block		4201
2	550349	connector block		13162
3	365042	interference suppression filter		1500
4	365041	filter		14726




Item	Order	Description	Model	OEM
1	400469	transformer		4233
2	350065	buzzer		13120


Electrical



Item	Order	Description	Model	OEM
1	400136	main p.c.b.	AL40E, AL41E, AL45E, AL46E, AF78E, AL_E/ AF78ED, AF_78E, AF78EPS, AF78ED??, AF88E	7738
2	400132	EPROM	AL40E, AL45E	7728
2	400133	EPROM	AL41E, AL46E	7722
2	400186	EPROM	AF78E, AF88E	7735
2	400131	EPROM	AT	7729



Item	Order	Description	Model	OEM
1	400137	display p.c.b.	AL_E, AF78E, AF78EPS, AF78ED, AF78EDP, AF88E	7721
2	400185	display p.c.b.	AT112 to AT116	7733



Item	Order	Description	Model	OEM
1	400465	fascia	AL_E, AF_E	7714
2	400470	fascia	AT112 to AT116	9673




Item	Order	Description	Model	OEM
1	379064	sensor	AL_E, AF_E, AT112 to AT116	7723



Item	Order	Solenoid valves	Model	OEM
1	370015	single	AL10, AL20, AL03, AL54, AL55, AF73, AF88	7604, 2504
2	370019	double	AL30, AL40, AL35, AL45, AL50, AL60, AL11, AL21, AL15, AL25, AL54D, AL55D, AF61 to AF78 (from 1.3.00), AL16, AL26, AL40D, AL46D (from 1.3.00), AL05, AL05D, AL31, AL36, AL41, AL46	1066, 7374, 7214
3	370138	single with one coil	AL31, AL41, AL36, AL46, AL16, AL26, AF61DPS to AF78DPS, AF61D to AF78D	7209

Motors


Item	Order	Description	Model	OEM
1	500194	hood motor	AT112 to AT116	9620

Dosing pumps


Item	Order	Description	Model	OEM
1	361004	rinse aid - solenoid	AL30 to AL60, AF73 to AF88, AT95 to AT106	1076
2	361221	rinse aid - pressure	AL03 to AL60, AF61 to AF88, AT95 to AT116	7945




Item	Order	Description	Model	OEM
1	361260	detergent pump		5685
2	361261	controller		5669



Item	Order	Description	Model	OEM
1	361320	detergent/ dosing pump		7970



Item	Order	Description	Model	OEM
1	516112	rinse central container	AL30 to AL46	1077
2	516111	cap	AL30 to AL46	1073
3	516126	rinse central container	AL50, AL60, AF73 to AF88, AT95 to AT106	4146



Item	Order	Description	Model	OEM
1	516093	rinse central container	AL30 to AL46 (from 30.3.94), AT95 to AT106	7959
2	516189	funnel	(from 1.5.94)	7969
3	516098	connection piece		7920




Item	Order	Description	Model	OEM
1	516095	suction tube	AL30 to AL46 (from 30.3.94), AT95 to AT106	7922
2	n. l. a.	connecting piece		7921
3	516096	filter	(from 1.5.94)	7931



Item	Order	Description	Model	OEM
1	361141	bottle weight/liquid		1515
2	516113	bottle weight/liquid		1516
3	516127	elbow		4252
4	516174	electrode sensor		5672


A

Suitable for Ata




Item	Order	Description	Model	OEM
1	361262	suction tube		4219
2	400469	transformer		4233
3	380478	contactor, 24V		4241
4	350065	buzzer		13120

Heating elements



Item	Order	Description	Model	OEM
1	415043	2500W	AL30 to AL46, AL54, 7204 AL55 (tank), AL50, AL60 (tank), AL10, AL20 (tank), AL03, AL05 (tank)	
2	415044	3000W	AL50, AL60 (boiler), AL54, AL55	4205
3	415330	tank, 1500W	AL10 to AL20, AL03, AL05	1102




Item	Order	Description	Model	OEM
1	415249	tank, 1500W	AL10 to AL26 (from 30.3.94)	7609
2	415042	2200W		1020



Item	Order	Description	Model	OEM
1	415330	1500W/230V	AL03, AL05, AL10 to AL20	1102
2	416127	1800W/230V	AL40, AL45	6816



Item	Order	Description	Model	OEM
1	415158	2500W/230V		
2	415248	2185W/230V	AF61, AF73	4360



Item	Order	Description	Model	OEM
1	415249	1500W/230V	AL10 to AL26 (from 30.3.94)	7609
2	415043	2500W/230V	AL03 to AL60	7204
3	415044	3000W/230V	AL50 to AL60, AF73, AF78, AT95 to AT116	4205



Item	Order	Description	Model	OEM
1	415045	4500W/230V	AF73 to AF88, AF61	5205
2	415808	6000W	AF73 to AF88 (from 1.10.98), AT95 to AT106	5505
3	416029	6000W	AT95 to AT106	6205




Item	Order	Description	Model	OEM
1	510408	heater gasket		
2	516135	insulation	AF61 to AF78	4367

Boilers



Item	Order	Description	Model	OEM
1	n.l.a.	boiler	AL30, AL40, AL30, AL40, AL35, AL45	7505, 7057
1	516233	boiler	AL50, AL60, AF73 to AF78	4150
2	516163	boiler	AL10 to AL26 (from 30.3.94), AL30, AL40, AL35, AL45 (from 3.3.94)	7890




Item	Order	Description	Model	OEM
1	516162	boiler	AL31, AL36, AL41, AL46 (from 3.3.94)	7857, 7057
2	516147	boiler	AL03, AL05, AL03D, AL05D	7330
3	516041	boiler	AL54, AL54D, AL55, AL55D, AF61 to AF88 (from 1.10.98)	4496
3	516234	boiler	AL50, AL60 (from 30.3.94), AT105 (Zusatz), AF73 to AF88 (from 30.3.94)	4577



Item	Order	Description	Model	OEM
1	516182	boiler	AL41E, AL46E, AL40E, AL45E	6743
2	516190	boiler	AT95, AT105	9564
3	516181	boiler	AT105, AT110, AT116 (1.10.98)	6528

Pumps

Drain pumps




Item	Order	Description	Model	OEM
1	500052		AL50PS, AL60PS, AF73PS, AF78PS	4236
2	500195		AL40ET, AL45ET, AL40E, AL45E, AL40PS, AL45PS, AL41E, AL46E, AF78E, ED, EDP, AF88E	7965



Item	Order	Description	Model	OEM
1	500209	motor	AL40PS, AL45PS, AL55PS	4751
2	500197	housing	(from 1.10.98): AF61D to AF78D, AF61DPS to AF78DPS, AF61PS to AF78PS	9616

Wash pumps



Item	Order	Power	Voltage	Phases	Model	OEM
1	500180	0,15HP	230V	1	AL03 to AL16	7650, 7670
2	500181	0,40HP	230V	1	AL20 to AL26, AL40, AL45 (from 1.3.00)	7655
3	500149	0,37HP	230V	1	AL30 to AL46	7207



Item	Order	Power	Voltage	Phases	Model	OEM
1	500188	0,5PHP	230V	1	AL30, AL35, AL40, AL45 (from 30..3.94)	7955, 7274
2	500183	0,5HP	230V	1	AL41, AL46 (30.3.94)	7956
3	500192	0,75HP	230V	1	AAL54, AL55	4715

A

Suitable for Ata




Item	Order	Power	Voltage	Phases	Model	OEM
1	500185	1HP	230V	1	AL50, AL60, AF73, AF78	4630
2	500184	0,75HP	230V	1	AL50, AL60 (from 30.3.94), AF73, AF78 (from 30.3.94)	4683
3	500189	0,5HP	230V	1		4279



Item	Order	Power	Voltage	Phases	Model	OEM
1	500273	1,5HP	380V	3	DTST, AT96	6650
2	500272	1,2HP	380V	3	AT105, AT106	6600
3	500186	1,5HP	380V	3	AT95 (from 1.5.94), AT112	9808
3	500187	2HP	380V	3	AT108 (from 1.5.94)	9806



Item	Order	Power	Voltage	Phases	Model	OEM
1	500198	1HP	380V	3	AF88	5630
2	500190	0,75HP	230V	1	AF61, AF78 (from 1.10.98)	4710
3	500191	1HP	380V	3	AF88 (from 1.10.98)	4757



Pumps		1 Impellor		2 Mechanical seal		3 Housing gasket		4 Pump cover		5 Capacitor	
Order	OEM	Order	OEM	Order	OEM	Order	OEM	Order	OEM	Order	OEM
500149	7207	521233	7251	510693	7252, 7253	521716	7254	521541	7250	365015	
500180	7670	521222	7678	510692	7677	521704	7676	521518	7679	365013	
500181	7655	509028	7685	510693	7684	521708	7683	521528	7686	365015	
500183	7956	521233	7251	510693	7252, 7253	521716	7254	521560	7233	365015	
500184	4683	509021	4702	510692	4703	521709	4704	521530	4701	365014	
500185	4630	521271	4635	510692	4634	521721	4633	521549	4636	365014	
500186	9808	521241	14115	510693	7684	521712	6633	521537	14101	-	
500187	9806	521243	14115	510693	7684	521712	6633	521537	14101	-	
500188	7274	509028	7685	510693	7684	521716	7254	521541	7250	365015	
500190	4710	509021	4702	510692	4703	521709	4704	521530	4701	365014	
500191	4757	509021	4702	510692	4703	521709	4704	521530	4701	-	
500192	4715	509021	4702	510692	4703	521709	4704	521530	4701	365014	
500198	5630	521251	4635/1	510693	4634	521719	4633	521546	4636	-	
500272	6600	521251	4635/1	510693	4634	521719	4633	521546	4636	-	
500273	6650	521241	6632	510693	4634	521712	6633	521535	6631	-	
500189	7279	509028	7685	510693	7684	521716	7254	521541	7250	365015	

easicook.co.uk

Spare Parts Manual

Leading UK Distributors
of Catering Equipment Since 1977

Sales - Repairs - Spares

Tel: 029 20747567

Fax: 029 20214100

Email: info@easicook.co.uk

[Click Here for Live Online Chat](#)