

easicook.co.uk

Spare Parts Manual

Leading UK Distributors
of Catering Equipment Since 1977

Sales - Repairs - Spares

Tel: 029 20747567

Fax: 029 20214100

Email: info@easicook.co.uk

[Click Here for Live Online Chat](#)

PARTI DI RICAMBIO
PIECES DETACHEES
SPARE PARTS
ERSATZTEILE
LISTA DE RECAMBIOS

FC 53

10/94

FC 54

10/94

FC 533

01/96

FC 543

10/94

FC 544



10/94

FC HR ...

10/94

FC ... / A


10/94



02 - 1999 S. AG.

FC54A




Hood



06 - 2001 S. AG.





FC54A

Wash arm




FC54A

Rinse arm



FC54A


Tank



05 - 2002 | S. AG.


FC54A

Wash





05 - 2001 S. AG.

FC54A
Water softener




FC54A

Pump



FC54A


Rinse aid injector



02 - 2004 S. AG.

FC54A


Control box 53 - 54





02 - 1999 | S. AG | 01

FC54A

Control panel with electronic timer



FC54A
Drain pump



05 - 2001 S. AG.

FC54A
Detergent dispenser

620242

200467

251213

260408

200607

180719

10 - 2000 S. AG.

